



ULTIMATE DARK MATTE

APPLICATION INSTRUCTIONS

STEP BY STEP

Step 1

Feed material into inkjet printer so that the printer is printing on the printable side (white matte coated side).

Step 2

Design your image and place your cut lines. Print and Cut your design right reading.

Step 3

Weed away excess material using tweezers or weeding tool.

Optional:

For designs with small pieces, use MultiTack Medium.

Step 4

Prepress fabric.
Remove backing
material and place on
shirt with image face
up. Place silicon sheet
on top of image.

Step 5

Heat apply the material onto the shirt. Press at 330°F for 15 seconds. Use medium pressure. Do not use Teflon sheets when pressing.

Step 6

Peel silicon sheet warm.

APPLICATION

Printing Inks
Image
Press Time:
Temperature:
Pressure:
Solvent, Eco Solvent
Right Reading
15 seconds
15 medium
Medium

Suggested Blade: 45 degree
Suggested Force: 40-75g
Peel: Warm

Wash Temp.: Up to 175°F (80°C)

Do not use Teflon sheets when pressing All technical information and recommendations are based on tests we have conducted.

Users should conduct their own tests before proceeding

Notes

Recommended Fabrics

100% cotton 100% polyester* Poly/cotton blends Polyester knits* Polyester mesh* Poly/foam & cotton caps Satin

Accessories Required

Computer, Inkjet Printer with Solvent, Eco-Solvent, Cutter, Heat Press

Printable side

The printable side (white matte coated side) is on the outside of the roll.

Cutting Notes

You should always test cut prior to any production run. Remember cutter settings will need to be adjusted as your blade ages. For optimal cutting and weeding, maintain a line thickness of at least 1/8" for lettering & logos.

Please allow 2-4 hours before stretching after pressing

Care Instructions

Wait 24 hours before washing.
Machine wash using mild detergent.
Do not use bleach or other aggressive cleaning agents. Cannot be dry cleaned. Wash Temperature cannot exceed 175°F.

Storage

MultiPrint Ultimate Dark Matte has an indefinite shelf life when stored at room temperature. Keep away from direct heat, sunlight and humidity.



After Heat Press Application

^{*}Some polyester garments may experience dye migration, prior testing should be conducted