

Sublimatable Sequin Pillows

SUBLIMATION

Printing

For Epson SureColor Series, please use a fabric profile. For sublijet users, please use either the Sawgrass Print Manager. Use the setting "Polyester". All images should be MIRRORED unless specified below.

Important

When the image is printed, it may look dull on the paper—this is normal. Trim the image to make it easier to position on your item. Secure your image to the object with heat tape to keep it from slipping or shifting.

When pressing is done, open the press slowly and gently remove the paper (be careful not to let the paper shift across the surface of the object, or you may create a "ghost" image). When the object is removed from the press, just let it cool. Do not let printed areas touch while hot, as this will affect image quality

Heat Press Setup

Set your heat press to 360°F. Before pressing, test the pressure. The pressure should be **medium**. Ensure that your press has reached 400°F before pressing. Ensure that the zipper is outside of the heat press platen.

Protect your heat press with at least two pieces of plain paper underneath your substrate and on top of your substrate. When sublimating to the non-sequin side, please insert a piece cardboard inside to ensure an even print.

Pressing

Press Temperature: 360°F | Press Time 120 seconds Medium Press, Hot Peel

- 1. Place two pieces of plain paper on your heat press.
- 2. a) Tape imaged sublimation paper to the pillow case with heat tape. The printable sides should be facing each other.
 - b) It is recommended, you sublimate the sequin side first if you plan to sublimate both sides.
- 3. Place the pillow case with taped imaged sublimation paper in heat press with the paper on top
- 4. Place a piece of plain paper on top to protect your platen.
- 5. Press at **360°F** for **120 seconds**.
 - Note: Do NOT use a Teflon sheet when pressing.
- 6. Once pressing is done, immediately peel off sublimation paper.
- 7. Leave pillow case to cool on a table

Note: For double sided prints, print each side separately. Sublimate the sequin side first if possible.

For Technical Support and to Re-Order

Tel: 1-800-565-5686 | Fax: 1-800-565-5622 | www.jotoimagingsupplies.com Blaine WA, Las Vegas NV, Nashville TN, Coquitlam BC, Brampton ON