

20oz Stainless Steel Mug

SUBLIMATION

Printing

When using SubliJet refer to the Sawgrass Print Manager Manual. If using Epson or another brand of ink, use the instruction manual provided from the vendor you purchased your ink from. All images should be MIRRORED unless specified below.

Important

When the image is printed, it may look dull on the paper—this is normal. Trim the image to make it easier to position on your item. Secure your image to the object with heat tape to keep it from slipping or shifting.

When pressing is done, Open the press slowly and gently remove the object and remove the paper (be careful not to let the paper shift across the surface of the object, or you may create a "ghost" image).

Heat Press Setup

Before pressing, test the pressure using a blank mug. The pressure should be light. Adjust pressure accordingly. Ensure that your mug press has reached the idle or press temperature before using.

Do not use excessive pressure. Doing so will damage your mug press and damage your item.

Pressing

OVERVIEW

Press Temperature: 360° F for 60 seconds

Light Pressure, hot peel

Recommended Printable area when using a mug press: Approx. 3.3"W x 6.61"H.

1. Remove lid and straw.
2. Tape imaged sublimation paper onto your stainless steel mug. Image facing the mug. Leave a 0.5" margin between the top rim and the top of your image.
3. Set the mug press at **360° F** for **60 seconds**. If your press has an idle and press temperature setting, adjust the time accordingly.
4. Ensure the mug press has reached temperature, place the mug into your mug press.
5. Close the Mug Press.
6. Once pressing is done, open the mug press, and take mug out of the press. Use gloves or heat-resistant cloth to handle the hot mug.
7. Peel sublimation paper off.
8. Leave on the table to cool. **Do not dunk in water.**

Caution: Mug is extremely hot when in the heat press, do not handle with bare hands

Note: Temperature and time settings are only a guide/starting point, some mug presses may require some fine tweaking of the temperature and time.

For Technical Support and to Re-Order

Tel: 1-800-565-5686 | Fax: 1-800-565-5622 | www.jotoimagingssupplies.com
Blaine WA, Las Vegas NV, Nashville TN, Coquitlam BC, Toronto ON